

CPU

Holders and Mounts



CPU holders and mounts, protect your computer equipment and work comfortably.

Set your workstation the way you want to, with the **Dual strap CPU holder**. It fits every computer to any desk and it's extremely easy to setup. Reduce the risk of bumping into the computer and damaging its electronic components, with this easy-to-use desktop solution.



Dual strap CPU holder

- Adjustable straps for any size CPU
- Soft touch anti-slip pad
- Slides to store
- 360° Swivel
- Available as an option on upCentric™ tables
- Width adjustment: 64" max
- Weight capacity: 20 lbs

Warranty

5 Years

The **CPU clamp mount** is the perfect accessory for the contemporary work environment. It provides the perfect fit and stability to your workstation setup; all the time, every time. Its intuitive design allows to easily switch computers when needed, and provides easy access to all of the rear panel connections.



CPU clamp mount

- Height and width adjustable frame for any size CPU
- Increased stability and clamp force
- Perfect for easily mounting and dismounting
- Slides to store
- 360° Swivel
- Available as an option on upCentric tables
- Height range: 14.5" to 22.5"
- Width range: 3.5" to 9.3"
- Weight capacity: 80 lbs

Warranty

5 Years