

# Seating sizes guide

SEAT SIZE						
Chair Series	Extra Small	Small	Large/Standard	Plus Size	Extra Long	Extra Deep
tCentric Hybrid™ Mesh Seat	–	20"w x 16 ½"d TMBMSS/TLGMSS	21"w x 18 ½"d TMBMS/TLGMS	–	21"w x 21 ½"d TMBMXLS/ TLGMXLS	–
tCentric Hybrid™	17 ½"w x 15 ½"d XSS	18 ½"w x 17"d SS	20"w x 19"d LS	22"w x 19"d PS	20"w x 21"d XLS	22"w x 21"d XPS
airCentric™	17 ½"w x 15 ½"d XSS	18 ½"w x 17"d SS	20"w x 19"d LS	22"w x 19"d PS	20"w x 21"d XLS	22"w x 21"d XPS
Saffron / Saffron R	17 ½"w x 15 ½"d XSS	18 ½"w x 17"d SS	20"w x 19"d LS	22"w x 19"d PS	20"w x 21"d XLS	22"w x 21"d XPS
geoCentric™	17 ½"w x 15 ½"d XSS	18 ½"w x 17"d SS	20"w x 19"d LS	22"w x 19"d PS	20"w x 21"d XLS	22"w x 21"d XPS
ecoCentric™	17 ½"w x 15 ½"d XSS	18 ½"w x 17"d SS	20"w x 19"d LS	22"w x 19"d PS	20"w x 21"d XLS	22"w x 21"d XPS
eCentric™	17 ½"w x 15 ½"d XSS	18 ½"w x 17"d SS	20"w x 19"d LS	22"w x 19"d PS	20"w x 21"d XLS	22"w x 21"d XPS
myCentric™	17 ½"w x 15 ½"d XSS	18 ½"w x 17"d SS	20"w x 19"d LS	22"w x 19"d PS	20"w x 21"d XLS	22"w x 21"d XPS
ergoForce™	17 ½"w x 15 ½"d XSS	18 ½"w x 17"d SS	20"w x 19"d LS	22"w x 19"d PS	20"w x 21"d XLS	22"w x 21"d XPS
Specialty Seating	17 ½"w x 15 ½"d XSS	18 ½"w x 17"d SS	20"w x 19"d LS	22"w x 19"d PS	20"w x 21"d XLS	22"w x 21"d XPS
Chair Series	Small	Small Heavy Duty	Large/Standard	Large Heavy Duty	Plus Size	Extra Wide
eCentric Executive™	20"w x 17"d 24CSS	24"w x 19"d SSHHD	20"w x 19"d 24CSTD	24"w x 21"d LSHD	22"w x 21"d 24CPS	22"w x 19"d 24CXW
24Centric™	20"w x 17"d 24CSS	24"w x 19"d SSHHD	20"w x 19"d 24CSTD	24"w x 21"d LSHD	22"w x 21"d 24CPS	22"w x 19"d 24CXW
Chair Series	Small	Small Heavy Duty	Large/Standard	Large Heavy Duty	Plus Size	Extra Wide
e500™	–	–	22"w x 21"d 24CPS	24"w x 21"d E5LSHD	–	26"w x 21"d E5XW



tCentric Hybrid All Mesh



airCentric



eCentric Executive