


tCentric Hybrid Lumbar Support – Installation Guide

1. Remove the back cap on the tCentric Hybrid. Instructions can be found here: <https://youtu.be/X-QNBXuk9Pk>
2. Pull back on the back-height lever and extend the backrest so that it is at its highest position.
3. Locate the 2 marks inside the back to drill holes for the lumbar support. Using a 5/16 drill bit, open up these holes. Be sure to put a barrier between the back column and the mesh, so as to avoid drilling through and potentially damaging the mesh.



4. Maneuver the lumbar support between the backrest column and the mesh. Align the holes in the lumbar support with the two holes that were drilled in *Step 3*. Using a #3 Phillips screwdriver, fasten the lumbar support to the backrest using 2 M6x25 pan head screws (2a, b, c, d).



5. Replace the back cap. Instructions can be found here: <https://youtu.be/X-QNBXuk9Pk>